RIGGING ROBOTS IN OMNIVERSE

ELA NUÑEZ

SUMMER 2024

NAVAL RESEARCH LABORATORY HBCU/MI INTERN

DISTRIBUTION STATEMENT A — APPROVED FOR PUBLIC RELEASE, DISTRIBUTION IS UNLIMITED

IMITATIVE LEARNING

- Training robots
- Expert data
- Rewards for autonomy





NVIDIA ISAAC-SIM OMNIVERSE

- Simulation software
- Fine-tuning
- Efficient





• Kinova G3 arm

Position, velocity, and force control

finger_joint and right_outer_knuckle_joint

https://robotiq.com/products/2f85-140-adaptive-robot-gripper?ref=nav_product_new_buttons


METHODS

- "Rigging complex structures" tutorial
 - Import CAD
 - Add joints
 - Break articulation loop
 - Add joint drives, colliders, and mimic joint
 - Create simulation environment
- 1 change at a time
- Troubleshooting: keywords, Isaac-Sim forums/docs, blogs, A.I., YouTube, team



https://docs.omniverse.nvidia.com/isaacsim/latest/advanced tutorials/tutorial advanced rigaing complex structures.htm

RESULTS








CONCLUSIONS

- Broken right finger
- Joint articulation = tree
- Iterations need time
- ullet Damping controls Δv , stiffness controls Δd
- Replaceable fingertips!
- Update software



CONTROL THEORY

PD controller: control_effort = self.kp * pos_error + self.kd * vel_error




https://medium.com/@svm161265/when-and-why-to-use-p-pi-pd-and-pid-controller-73729a708bb5

System output

System

ISAAC-LAB

- Articulation → robot
- Base code
- Python



https://isaac-sim.github.io/lsaacLab/source/tutorials/01_assets/run_articulation.html

METHODS

- Create articulation class for rigged gripper
- Apply ideal PD actuator to articulation
- Use "run_articulation.py" as base code to control gripper
 - Initialize gripper as open
 - While simulation is running, apply actuator and update step
 - If the sim step < 100: dose gripper
 - If sim step >= to 100: open gripper
 - If sim step = 200: reset gripper
- Use "arms.py" as base code to control KG3
 - Initialize KG3 as upright with Robotiq attached
 - While simulation is running, apply actuator and update step
 - If sim step < 200: arm in rest position, gripper open
 - If sim step > 200: arm moves, gripper closes
 - If sim step = 400: reset assembled robot
- Troubleshooting: import pdb, IsaacLab docs/forums, ERROR messages, A.I., rubber ducky method

https://isaac-sim.github.io/lsaacLab/source/setup/sample.html

RESULTS

PhysX hack

```
# resolve articulation rest prime back into regex expression
roct_prim_path = roct_prime_bid_erroct_prim_path * roct_prime_bid_erroct_prim_path) : ]
# control_prim_path = roct_prime_bid_erroct_prim_path * roct_prime_bid_erroct_prim_path) : ]
# control_prim_path = roct_prime_bid_erroct_prim_path * roct_prim_path | roct_prim_path
```

pdb and robot_assembler hack

```
-> assembled_robot = robot_assembler.assemble_articulations(
> /isaac-sim/exts/omni.isaac.robot_assembler/omni/isaac/robot_assembler.py(555)_move_obj_b_to_local_pos()
-> a_trans, a_orient = XFormPrim(base_mount_path).get_world_pose()
> /isaac-sim/exts/omni.isaac.robot_assembler/omni/isaac/robot_assembler/robot_assembler.py(557)_move_obj_b_to_local_pos()
-> a_rot = quats_to_rot_matrices(a_orient)
(Pdb) s
---Call---
> /isaac-sim/exts/omni.isaac.core/omni/isaac/core/utils/numpy/rotations.py(107)quats_to_rot_matrices()
-> def quats_to_rot_matrices(quaternions: np.ndarray, device=None) -> np.ndarray:
> /isaac-sim/exts/omni.isaac.core/omni/isaac/core/utils/numpy/rotations.py(116)quats_to_rot_matrices()
-> if len(quaternions.shape) == 1:
(Pdb)
def _move_obj_b_to_local_pos(base_mount_path, attach_path, attach_mount_path, rel_offset, rel_orient):
    # Get the position of base_mount_path as `a`
    import pdb
    pdb.set_trace()
    a_trans, a_orient = XFormPrim(base_mount_path).get_world_pose()
    a_trans = np.asarray(a_trans.cpu())
    a_orient = np.asarray(a_orient.cpu())
    a_rot = quats_to_rot_matrices(a_orient)
    rel_rot = quats_to_rot_matrices(rel_orient)
```

```
# The attach_mount_path local xform is a free variable, and setting its world pose doesn't # change the world pose of every part of the Articulation.

# We need to set the position of attach_path such that attach_mount_path ends up in the # desired location. Let the attach path location be 'b'.

# t_bc denotes the translation that brings b to c
# r_bc rotates from b to c

t_bc, q_bc = XFormPrim(attach_mount_path).get_local_pose()

t_bc = np.asarray(t_bc.cpu())

q_bc = np.asarray(d_bc.cpu())


r_bc = quats_to_rot_matrices(q_bc)

b_rot = c_rot @ r_bc.T
b_trans = c_trans - b_rot @ t_bc
b_orient = rot_matrices_to_quats(b_rot)

XFormPrim(attach_path).set_world_pose(b_trans, b_orient)
```

RESULTS

Robot assembler



CONCLUSIONS

- USD files manipulated in IsaacLab must contain ONLY robot w/ articulation root
- PhysX error: To grab "body view" in articulation.py we must grab all prims in "root view"
 - Utility: run_articulation_robotiq.py
- Robot_assembler data type error: requires a numpy array in _move_obj_b_to_local_pos
 function but grabs a cuda tensor
 - Utility: kg3_test.py
- Velocity control allows grasp
- Changing gripper's direction of motion using controller results in massive torque

FUTURE DIRECTIONS

- Train gripper in sim
- Follow target example
- Train hardware using sim data
- Deformable force sensors